


# TYPICAL WIRING DIAGRAM



NOTE 1  
THESE GROUND CONNECTIONS MUST BE ON THE ENGINE BLOCK, AND MUST BE TO THE SENDER BODIES.  
THE GROUND WIRE TO TERMINAL 47 MUST NOT BE USED TO PROVIDE A GROUND CONNECTION TO ANY OTHER DEVICE


**DIMENSIONS** : 240mm x 172mm x 57mm  
(9.5" x 6.8" x 2.25")  
**PANEL CUTOUT** : 220mm x 160mm  
(8.7" x 6.3")




## 5320 INSTALLATION INSTRUCTIONS

### ACCESSING THE FRONT PANEL CONFIGURATION EDITOR

- Press the Stop/Reset and Info buttons simultaneously
- If a module security PIN has been set, the PIN number request is then shown (The first \* is flashing) :




- Press + or - buttons to adjust it to the correct value. Press ✓ when the first digit is correctly entered. Repeat this process for the other digits of the PIN number.
- When ✓ is pressed after editing the final PIN digit, the PIN is checked for validity. If the number is not correct, the editor is automatically exited. To retry you must re-enter the editor as described above.
- If the PIN has been successfully entered (or the module PIN has not been enabled) the first configurable parameter is displayed :



### EDITING A PARAMETER

- Enter the editor as described above.
- Press the + and - buttons to cycle to the parameter you wish to change.
- Press the ✓ button to enter edit mode. When in edit mode (indicated by the flashing parameter) pressing the + and - buttons will adjust the parameter to the desired value.
- For *date and time* editing only: press to select between day, month, year, hours and minutes.
- Press the ✓ button to 'save' the value. The value will stop flashing to confirm that it has been saved.
- To select another value to edit, press the + button. Continuing to press the + and - buttons will cycle through the adjustable parameters as shown overleaf.
- To exit the front panel configuration editor at any time, press the Stop/Reset button. Ensure you have saved any changes you have made by pressing the ✓ button first.



**NOTE:-** When the editor is visible, it is automatically exited after 5 minutes of inactivity to ensure security.

**NOTE:-** The PIN number is automatically reset when the editor is exited (manually or automatically) to ensure security.

**NOTE:-** More comprehensive module configuration is possible using the 5xxx series PC configuration software in conjunction with the P810 PC interface. Please contact us for further details.

<p><b>Deep Sea Electronics Plc.</b> Highfield House, Hunmanby Industrial Estate, North Yorkshire. YO14 0PH. ENGLAND Tel:+44 (0)1723 890099. Fax: +44 (0)1723 893303. LO CALL (from UK BT landlines) : Telephone 0845 260 8900. Fax 0845 260 8901 Email: sales@deepseapl.com Web: www.deepseapl.com</p>	<p><b>Deep Sea Electronics inc.</b> 3230 Williams Avenue Rockford, Illinois 61101-2668, U.S.A. Phone: +1 (815) 316-8706. Fax: +1 (815) 316- 8708 TOLL FREE (USA only) : Tel: 1 866 636 9703 Email: dsesales@deepseausa.com Web: www.deepseausa.com</p>
--	--

## ADJUSTABLE PARAMETERS (Factory default settings are shown in bold italicised text)

Section	Parameter	Display shows	Values	
Input settings	Low Oil Pressure warning	Oil pressure pre-alarm	0-4bar ( <b>1.17bar</b> )	
	Low Oil Pressure shutdown	Oil pressure shutdown	0-4bar ( <b>1.03bar</b> )	
	High Temperature warning	Coolant temp pre-alarm	80-140°C ( <b>115°C</b> )	
	High Temperature shutdown	Coolant temp shutdown	80-140°C ( <b>120°C</b> )	
	Low Temperature warning	Low Coolant temp	0-138°C ( <b>64°C</b> )	
Timers	Mains transient delay	Mains transient delay	0-30s ( <b>2s</b> )	
	Generator transient delay	Generator transient delay	0-30s ( <b>0s</b> )	
	Start delay	Start delay	0-10h ( <b>5s</b> )	
	Return delay	Return delay	0-5h ( <b>30s</b> )	
	Preheat	Preheat	0-5m ( <b>0s</b> )	
	Crank attempt	Cranking time	0-60s ( <b>10s</b> )	
	Crank rest	Crank rest	0-60s ( <b>10s</b> )	
	Safety delay	Safety on	0-60s ( <b>10s</b> )	
	Overspeed overshoot	Overspeed overshoot	0-10s ( <b>2s</b> )	
	Warming up	Warm up	0-60m ( <b>0s</b> )	
	Transfer delay	Transfer delay	0-10m ( <b>0.7s</b> )	
	Cooling run	Cooling	0-60m ( <b>60s</b> )	
	Fail to stop delay	Fail to stop	0-2m ( <b>30s</b> )	
	Low battery volts delay	Battery low delay	0-24h ( <b>60s</b> )	
	High battery volts delay	Battery high delay	0-24h ( <b>60s</b> )	
	Mains (utility)	Mains Low Voltage	Mains undervolt trip	50-360V ph-N ( <b>184V</b> )
		Mains High Voltage	Mains overvolt trip	50-360V ph-N ( <b>276V</b> )
Mains Low Frequency		Mains underfreq trip	0-75Hz ( <b>45Hz</b> )	
Mains High Frequency		Mains overfreq trip	0-75Hz ( <b>55Hz</b> )	
Generator	Generator Under voltage shutdown	Generator low voltage shutdown	50-360V ph-N ( <b>184V</b> )	
	Generator Under voltage prealarm	Generator low voltage prealarm	50-360V ph-N ( <b>196V</b> )	
	Generator Over voltage prealarm	Generator high voltage prealarm	50-360V ph-N ( <b>265V</b> )	
	Generator Over voltage shutdown	Generator high voltage shutdown	50-360V ph-N ( <b>276V</b> )	
	Generator Under frequency shutdown	Generator low frequency shutdown	0-75Hz ( <b>40Hz</b> )	
	Generator Under frequency prealarm	Generator low frequency prealarm	0-75Hz ( <b>42Hz</b> )	
	Generator Over frequency prealarm	Generator high frequency prealarm	0-75Hz ( <b>55Hz</b> )	
	Generator Over frequency shutdown	Generator high frequency shutdown	0-75Hz ( <b>57Hz</b> )	
	Generator delayed overcurrent	Delayed high current	100-200% ( <b>100%</b> )	
	Engine	Underspeed (RPM) shutdown	Underspeed shutdown	0-6000RPM ( <b>1270</b> )
Underspeed (RPM) warning		Underspeed prealarm	0-6000RPM ( <b>1350</b> )	
Overspeed (RPM) warning		Overspeed prealarm	0-6000RPM ( <b>1650</b> )	
Overspeed (RPM) shutdown		Overspeed shutdown	0-6000RPM ( <b>1710</b> )	
Overspeed overshoot %		Overspeed overshoot	0-10 ( <b>0%</b> )	
Low DC Voltage		Battery low warning	0-40V ( <b>8V</b> )	
High DC Voltage		Battery high warning	0-40V ( <b>33V</b> )	
Charge Alternator Failure		Charge fail warning	0-39V ( <b>6V</b> )	
Display	Language	Language	<b>ENGLISH</b> , OTHER	

## ADJUSTABLE PARAMETERS (continued)

Section	Parameter	Display shows	Values
Application	Engine speed selection	Alternative Frequency	<b>Disable</b> , Enable
	Volts selection	Alternative Voltage	<b>Disable</b> , Enable
	AC System	AC System	<b>3 phase 4 wire</b> Single phase, 2 wire 3 phase, 3 wire 2 phase 3 wire (L1 & L2) 2 phase 3 wire (L1 & L3)
	Generator Full Load	Generator full load	0-6000A(500A)
	Droop control	Droop	<b>Disable</b> , Enable
		Droop	0% (0%-5%) Compatible engine ECUs only
	Frequency Adjust	Frequency Adjust	Cummins CM850 only
	LCD Contrast	Contrast	<input type="checkbox"/>   <input checked="" type="checkbox"/>
Date/Time	Date and Time	dd mmm yyyy hh:mm	

### ALTERNATIVE AC WIRING

**3 phase, 3 wire**  
For other AC systems please consult the module operators manual

