



Принципиальная схема генератора
"DENYO" DCA-45 SPI



MARK	N A M E
Ar	MAIN GENERATOR ARMATURE WINDING
Fg	MAIN GENERATOR FIELD WINDING
ExAr	EXCITER ARMATURE WINDING
ExFg	EXCITER FIELD WINDING
Re	RECTIFIER
AVR	AUTOMATIC VOLTAGE REGULATOR
VR	VOLTAGE REGULATING RHEOSTAT
CT1,3	CURRENT TRANSFORMER 150/5A
AS	AMMETER CHANGE-OVER SWITCH
A	AC. AMMETER 0~75, 150A
VS	VOLTMETER CHANGE-OVER SWITCH
V	AC. VOLTMETER 0~600V
F	FREQUENCY METER 45~65Hz
PL1	PILOT LAMP
CB1	CIRCUIT BREAKER 125A
SW1	PANEL LIGHT SWITCH
OC	OVER CURRENT RELAY
22	LEAKAGE CURRENT RELAY
C	CONDENSER
COT. B	VOLTAGE CHANGE-OVER BOARD



WIRE COLOR		WIRE COLOR	
B	BLACK	R	RED
L	BLUE	W	WHITE
BR	BROWN	Y	YELLOW
G	GREEN	LB	LIGHT BLUE
GR	GRAY	LG	LIGHT GREEN
V	VIOLET	O	ORANGE
P	PINK		

CAUTION. NO MARK WIRE SIZE: 1.25mm²

