



Принципиальная схема генератора
"DENYO" DCA-60 SPI

DCA-60SPI



MARK	N A M E
Ar	MAIN GENERATOR ARMATURE WINDING
Fg	MAIN GENERATOR FIELD WINDING
Ex Ar	EXCITER ARMATURE WINDING
Ex Fg	EXCITER FIELD WINDING
Re	RECTIFIER
AVR	AUTOMATIC VOLTAGE REGULATOR
VR	VOLTAGE REGULATING RHEOSTAT
CT1, 3	CURRENT TRANSFORMER 200/5A
AS	AMMETER CHANGE-OVER SWITCH
A	AC. AMMETER 0~100, 200A
VS	VOLTMETER CHANGE-OVER SWITCH
V	AC. VOLTMETER 0~600V
F	FREQUENCY METER 45~65Hz
PL1	PILOT LAMP
CB1	CIRCUIT BREAKER 150A
SW1	PANEL LIGHT SWITCH
OC	OVER CURRENT RELAY
22	LEAKAGE CURRENT RELAY
C	CONDENSER
COT. B	VOLTAGE CHANGE-OVER BOARD



COLOR CODE	
WIRE COLOR	WIRE COLOR
B BLACK	R RED
L BLUE	W WHITE
BR BROWN	Y YELLOW
G GREEN	LB LIGHT BLUE
GR GRAY	LG LIGHT GREEN
V VIOLET	O ORANGE
P PINK	

CAUTION. NO MARK WIRE SIZE: 1.25mm²

